

2560 Rosemead Blvd. So. El Monte, CA 91733 . (626) 443-2473 . Fax: (626) 443-9253

1.) Turn off all power to fixture prior to insatallation.

2.) Remove (2) 6-32 button socket head screw (provided) from cover & lens assembly & set cover & lens

3.) Detach (2) 6-32 pan head screws (supplied) from (2 pc.) wired channel & set (2 pc.) wired channel aside.

4.) Drill mounting holes as needed in sides or at back of housing (as shown) to secure fixture in desired location.

MOUNTING HOLES TO BE DRILLED IN SHADED AREAS ONLY

CAULK AROUND ALL MOUNTING HOLES & CONDUIT

5.) Connect conduit to K.O. on one or both sides of housing & make all wire connections (by E.C.).

6.) Replace (2 pc.) wired channel into housing & fasten in place with (2) 6-32 pan head screws previously

7.) Rettach cover assembly back in place with (2) 6-32 button socket head screws previously removed.

"THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE

## Lighting